


HULDA

SV Monteringsanvisning | EN Installation instruction



Innehåll | Contents

1. Dimensioner Dimensions	2
2. Avstånd soffa/bänk - bord Distance sofa/bench - table	7
3. Montering av HULDA i stål Assembly of steel HULDA	8
4. Ingjutning Casting	9
5. Fastbultning (under mark) Anchoring (below ground)	11
6. Modulära bänkar Modular benches	12

Smekab Citylife

Box 12160


S-291 12 Önnestad | SE





+46 (0)44 767 00

www.smekabcitylife.se


a SAFEROAD brand



1. Dimensioner | Dimensions










A-A










HUL805



HUL815



2. Avstånd soffa/bänk - bord | Distance sofa/bench - table




*

SV | Armstöd vid bord kan begränsa tillgänglighet.






EN | Armrests at tables can limit accessibility.

3. Montering av HULDA i stål | Assembly of steel HULDA





HUL100 HUL110 HUL200 HUL210

4. Ingjutning | Casting


HUL100 HUL110 HUL305 HUL505 HUL91X
HUL105 HUL115 HUL515



HUL200 HUL210 HUL405 HUL605 HUL805 HUL94X
 HUL205 HUL215 HUL615 HUL815






Gängad stång M12
Threaded bar M12




5. Fastbultning (under mark) | Anchoring (below ground)

HUL200 HUL210 HUL405 HUL605 HUL805 HUL94X
 HUL205 HUL215 HUL615 HUL815





BET112



6. Modulära bänkar | Modular benches

HUL912 HUL913 HUL91X



HUL942 HUL943 HUL94X